



# Hairpin Leg Installation Instructions

Other installation instructions available  
at [www.woodpro.com](http://www.woodpro.com)

## Tools and Supplies Needed:

### Tools

- 7/16" Wrench

### Supplies

- 4 - Shims in hardware bag, if needed
- 4 - 12" Hairpin Legs
- 12 - bolts (3 per leg)
- 12 - 1/4" x 20 hex nuts (3 per leg)

## Directions:

### 1. Remove Cabinet from the Carton.

- Remove loose pieces and drawers (optional)
- Remove and unwrap Hairpin legs

### 2. Lay Cabinet on its Back

- Locate the three bolts that are extending from the base (floor) of the cabinet in each of the 4 corners. Photo 1
- Remove the 1/4-20 Hex Nuts and set aside. Photo 1

### 3. Install each Hairpin Leg

- Install each Hairpin leg matching each corner of the leg into each corner of the vanity
- Using the 1/4-20 Hex Nuts that you removed attach each leg as shown in Photo 2 and tighten each nut
- To level the cabinet, if necessary, there are 4 shims that can be used. Back each nut and slip the "U" shaped shim where necessary between the top of the leg and bottom of the base.

### 4. Stand the cabinet upright

- Your leg should look like Photo 3.

