



# Pull Out Tray Installation Instructions

## SUGGESTED TOOLS AND SUPPLIES NEEDED

- ◆ Pull Out Tray
- ◆ Drill or Screw Driver
- ◆ Screws
- ◆ Tape Measure

1. Attach glides on each side of the pull out tray by placing tray onto glide and slide about  $\frac{3}{4}$  of the way out. Plastic end of the inner section of the glide will fit into outside edge of the under mount drawer lock. See Photo A.

Push the drawer box closed.

- ◆ Use quick, slight pressure
- ◆ A quick snap sound will be heard when the box has been installed correctly.
- ◆ This sound is the drawer lock connecting with the locking device clip on the glide.
- ◆ Holes in the back of the drawer box need to line up and fit in the grooves of the back section of the glide.
- ◆ Pointed clips on glide must be inserted into the holes in the back of the drawer box. See Photo B.
- ◆ **If drawer does not latch:**
- ◆ Hold drawer  $\frac{1}{2}$  way in, reach behind and slide glide forward to meet the drawer box, ensuring the metal prongs on the glides are aligned with the holes on the back of the drawer box.
- ◆ Push drawer and glide together until glide snaps in place.



Photo A



Photo B

2. Place pull out tray in the center of the cabinet base, behind frame rail so that the front brackets are about  $1 \frac{3}{4}$ " from the edge of the rail, so that the front of the box is not hitting the doors when they are closed. See Photo C



Photo C

3. Once the tray is in the exact position you want, have someone hold down the sides of the glides to keep them in place while you pull out the tray until the back brackets are visible and you can screw the glides into place. See Photo E Completely remove the drawer by pushing the green handles toward the center to release it from the glides. See Photo D Finish attaching the glides to the cabinet by screwing the front brackets in place. See Photo F

You can also take a pencil and outline the four brackets, then remove the tray, line up the brackets with the outlines and screw the brackets and glides into place.



Photo D



Photo E  
Back Bracket



Photo F  
Front Bracket

4. When the glides are secured reattach your tray to the glides following the same instructions as in Step 1.